

ASSEMBLY INSTRUCTIONS

Étagères à Fleurs

All hardware comes pre-attached to the product, Remove it and re-attach it as needed during assembly

On a soft, level surface, unpack and identify the following component parts.

- Bottom Shelf (1)
- Middle Shelf (1)
- Top Shelf (1)
- Legs (3)
- 27 3/4" Vertical Supports (3)
- 12 1/2" Vertical Supports (6)
- 24 Bolts, 1 Allen key

Please read the instruction completely prior to assembly. The only tools required are the enclosed Allen key. (Do not use the Allen key to secure the bolts until assembly is complete; hand tighten until snug).

1. Attach the three legs to the bottom shelf as shown. Place the groove in the leg against the bottom shelf with the bent "foot" facing inward. Insert a bolt through the predrilled holes and fasten onto the nut welded in place.

2. Attach the three 27 3/4" vertical supports to the bottom shelf. Align the grooves in the support with the predrilled holes at the back of the shelf as shown. Be sure that the bent "foot" is facing inward, then secure each support with a bolt.

3. Set the bottom shelf upright, Place the back of the middle shelf into the corresponding grooves in the 27 3/4" supports and secure with three bolts. Connect the middle shelf and the bottom shelf with three 12 1/2" vertical supports, anchoring each with two bolts.

4. Align the back of the top shelf with the grooves in the 27 3/4" supports and secure with three bolts. Connect three 12 1/2" supports to the top shelf and the middle shelf, anchoring each with two bolts.

5. Tighten each bolt with the Allen key.

